



## Hot Dog Rotisserie Instructions

Follow these instructions to operate the machine correctly. If you have any questions about proper use please call our office and ask for assistance (574) 259-4807. If the machine does not properly operate and it is after business hours choose the operator extension and leave a message in the voicemail.

1. Pour 1 ½ quarts into the water pan. Do not overfill. Use hot water
2. Place buns in the warmer basket
3. Place the hot dogs in the rotisserie
4. When you are ready to begin cooking move the switch to the ON position, this will rotate the rotisserie and the indicator bulb behind the screen will turn on
5. Time required to cook the hot dogs will vary based on size and preference

With the heat control set on HI average size hot dogs will be ready in approximately 10-15 minutes.

After the hot dogs are cooked reduce the heat control setting to one, which will keep the hot dogs warm but will not overcook them.